

Maintenance Procedure Card

Coast Guard Approved Type I and III PFDs

ITEM 1. COAST GUARD-APPROVED TYPE I AND III BUILD-UP PROCEDURE

PARTS REQUIRED

Selected Type I or III PFD

Personal Marker Light

ACR ® Firefly 3 TM Strobe light

Whistle(Fox 40)

Commercial

Commercial

8465 21 912 7031

TOOLS REQUIRED

1/2 Inch Stencils (marking pens with black indelible ink may be used in lieu of stenciling)

CONSUMABLES

Black Stencil Ink	7510 00 469 7910
Disinfectant/detergent	7930 01 346 4289
Hook Tape, 2",(Self-Adhesive)	Commercial Purchase
Type I Nylon Cord	4020 00 240 2154
Size AA Alkaline Batteries	6135 00 985 7845

1. Stencil a locally generated serial number on the Coast Guard approval label (marking pens with black indelible ink may be used in lieu of stenciling).

NOTE &

Steps 2 and 3 only apply to PFDs that will be worn without the boat crew survival vest.

CAUTION!

VERIFY ATTACHMENT OF D-RING AT WAIST. VESTS WITHOUT A D-RING SHALL BE REMOVED FROM SERVICE.

2. Attach the whistle to the PFD with a 24-inch piece of Type I nylon cord using a bowline followed by an overhand knot.

NOTE &

PFDs that will be used in temperatures below 50 degrees Fahrenheit shall use the strobe light in lieu of the personal marker light.

- 3. Clip the personal marker light to the PFD or attach the strobe light with a 36-inch piece of Type I nylon cord using a bowline knot followed by an overhand knot
- 4. Complete all steps in ITEM 2.
- 5. Record serial number and date placed in service on the Type I or III PFD maintenance log.



Maintenance Procedure Card

Coast Guard Approved Type I and III PFDs

ITEM 2. COAST GUARD-APPROVED TYPE I AND III SEMI-ANNUAL INSPECTION TOOLS REQUIRED and CONSUMABLES

See lists in ITEM 1 above.

- 1. Inspect the vest as follows.
 - a. Inspect vest pockets and casings for cuts, tears, seam separations, and loose stitching.
 - b. Inspect slide fastener for proper operation and security.
 - c. Inspect hardware for security of attachment, corrosion, damage, wear, and ease of operation.
 - d. Inspect Retro for condition and security of attachment.
 - e. Inspect vest markings for legibility. Restore as required
- 2. Inspect strobe light for the following
 - a. Obvious defects.
 - b. Check the security of the hook tape. Repair/Replace as required.
 - c. Remove and discard old batteries IAW local procedures.
 - d. Install new batteries. Do not over compress the gasket.
 - e. Activate the light and measure the flash rate. It shall be between 50 to 70 flashes per minute.
 - f. Replace lights that are broken or that do not flash at the desired rate
 - g. Check lanyard security and install in equipment pocket.
- 3. Inspect personal marker light tube seal and expiration date. If the seal is broken or 3 years from date of manufacture will elapse within the next 180 days, replace the light.
- 4. Inspect whistle.
 - a. Inspect whistle for seam separation and cracks. Damaged or defective whistles shall be replaced.
 - b. Blow whistle normally (regular exhalation); then with forced exhalation. If whistle fails to emit a highly audible sound, replace it
 - c. Wipe whistle
 - d. Check lanyard security and install in equipment pocket.

CAUTION!

DO NOT DRY PFDS IN A MACHINE DRYER. DRYER HEAT WILL CAUSE DAMAGE.

- 5. Hand-wash the PFD as required in a solution of water and disinfectant/detergent. Rinse completely and hang dry.
- 6. Record date and inspection complied with on the Type I or III PFD maintenance log.